

IDROCLEANER

Code SO1340

Odourless cleaner for rollers, brushes and other tools employed to apply water-based products.



DIRECTIONS

Rollers and brushes:

After using the roller or brush, wipe off from it as much as possible the product which it is soaked with, using a suitable wiper or paper or a cloth. Then wash the roller or brush with IDROCLEANER, dip it in a container with the cleaner and keep it there until you have to use it again. Before using the roller or brush again, make sure it is thoroughly clean and dry.

Accessoires: Clean accessoires with IDROCLEANER. If necessary, dip and keep them in a container with the cleaner until you have to use them again.

Before the new use, make sure any accessoire is thoroughly clean and dry.

Spray guns and spray equipments in general: At the end of the work pump into the equipments IDROCLEANER, at first diluted 100% with water then undiluted. Check the obtained cleanliness.

NOTICE

- Fill up the IDROCLEANER-bath when the cleaner is no more enough or renew it when the product is run down.
- **IDROCLEANER is not compatible with solvent-based products.**
- It should not be used to thin water-based products.

TECHNICAL DATA

(with room temperature of +23°C and 65% relative air humidity)

Appearance	colourless liquid
Viscosity	10" Ford cup 4
Specific weight	0,99
VOC	15%

Dispose of excess product and empty containers properly.

If the original unopened container is stored in a cool and dry place, the product will keep for at least 12 months.

N.B.: The information contained in this technical data sheet is correct to the best of our knowledge and experience. Since the conditions of use are beyond our control, no warranty is given or implied.